

PROGRAMMABLE SEGMENT TIMER INSTRUCTIONS- BRIEF

I. Turn power on AFTER controls are plugged in.

LCD Display: SEG 1 U 5 min.

II. To change automatic segment time, enter a number (1-99), then press “D” or “AUTO TIME” switch.

III. To change to a segment, enter a number (1-99), then press “A” or the

IV. “SEGMENT #” switch.

V. To program individual segments, go to the segment number (step III), then

enter the time by entering a number and pressing the “B” key or the “TIME” switch. Repeat as needed. Change the INTER-SEGMENT

TIME by entering a number and pressing the “F” key.

VI. The “E” key will change the counting mode from UP to DOWN to UP, etc...

VII. The “C” key or “START/ STOP” switch turns the timer on and off (“*” on the display= on); Timer must be off to make any changes.

NOTE: Turn power on AFTER the controls are plugged in. Changes cannot be made if asterisk (*) is showing.



HEADSETS



END ZONE CAMERAS



SOUND SYSTEMS



THE COACHPAD



DRONES



TIMERS & SCOREBOARDS



DOWN MARKERS



SPORTBOARDZ