Sony Camcorders DIGITAL PIGGY-BACK SYSTEM **HDMI** DC Plug Monitor Monitor Power Power supply / supply / camera camera Sinlge red button wil START/STOP Both camcorders Camera two zoom controls Camera one zoom controls (POWER)) Set the both monitors to input AV1 Adjustable angle plate Push quick release level All the way tight Monitor bracket knob

For immediate support call:

254-548-4723