

Connecting Remote to Pan/Tilt

Take the Male end of the Pan Tilt Cord and plug it into the female plug-in on the Pan Tilt



Connecting Remote to Camera
CAREFULLY plug in the Budget Remote's Multiport.



FRAGILE PLUG-IN On the right side of the camera toward the back, open the flap to expose the MultiPort plugin port. Plug the MultiPort cord into the MultiPort plugin port.



Connecting HDMI Cable to Camera

CAREFULLY plug in HDMI cord with Micro HDMI adapter.



FRAGILE PLUG-IN Run HDMI cord through the camera's hand strap, and then up and over the camera. Then the Micro HDMI plug is inserted into the port we uncovered earlier on the LEFT SIDE of the camera.



Using Remotes

Test Pan/Tilt functionality with remote to make sure camera is moving left/right/up/down. Test camera functionality with the remote and make sure camera zooms and records.



Pan Tilt Control

Camera Control