



#1 CHOICE FOR COACHING COMMUNICATION

Setup Instructions

High Riser Lite



HEADSETS



END ZONE CAMERAS



SOUND SYSTEMS



THE COACHPAD™



DRONES



TIMERS & SCOREBOARDS





DOWN MARKERS





SPORTBOARDZ

Set Up Instructions


- (1) Take the tower out of the bag.
- (2) Carry tower to the filming location.
- (3) Place the tower upright and loosen the top knob.



- (1) Open the tower legs.
- (2) To fully open, lift tower by the pole and press down on the top collar to spread out legs.
- (3) Extend legs as wide as possible.



- (1) Loosen the bottom knob and slide the pole down until it hits the ground.
- (2) Tighten the top and bottom knobs.



Take Down Instructions

Turn off all electronics: monitor, camera, and joystick.

Unhook the cable from the camera remote and monitor.

(1) Slowly loosen the first knob of the tower while keeping your other hand on the pole as a **brake**. (2) When the pole is loose enough to slide down, guide the pole all the way down with **both hands** and then (3) tighten the knob. Repeat with each pole section until the unit is completely lowered down.

IMPORTANT – Always have two hands on the tower while raising or lowering.

Now that the tower is down, unhook the top cable connections and strain relief and store the cable in the backpack. Take the pan tilt and camera off the tower and store.

Now store the joystick, camera remote, monitor battery, and monitor in the hard case. Next, take off the control plate and store in the backpack.

Once the electronics and control plate are off, loosen the top and bottom leg collar knobs and bring the legs up towards the tower. Be sure to lock the legs by tightening top knob.

IMPORTANT – Lower tower all the way before unlocking the legs.

